

REPAIR **PARTS** LIST

Model No.

116.35922500 116.35923500

> To Call Toll Free For Parts:

1-800-366-PART (1-800-366-7278)

For Service

1-800-4-MY-HOME (1-800-469-4663)



UPRIGHT VACUUM CLEANER

PACKAGING LIST

Your KENMORE VACUUM CLEANER is packaged with the following parts and components assembled separately in the carton

- Upright Vacuum Cleaner 1 Handle
- Combination Brush
- Owners Manual
- Crevis Tool
- 1 Parts List
- Telescopic Wand
- 1 Handi-Mate Jr.®
- 1 Extension Wand
- 1 Floor Brush

Each of the above assemblies are shown in detail inside this repair parts list.

The model number of your vacuum is found on the serial plate on the back of the unit.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Service Center, or the Service Department at most Sears stores. To order parts by phone, call the toll free parts number listed to the left.

When requesting service or ordering parts, always provide the following information:


- Product Type
- Part Number
- Model Number
- Part Description

Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.

NOZZLE PARTS

Illus								
No.	No.	DESCRIPTION						
1	KC01ACRCZCU7	Nozzle Housing						
2	488887	Lead Wire						
3	KC76KCJNZ000	Overload Protector						
4	KC02ACHDZVUS	Upper Body						
5	KC11ACHDZ000	Felt Seal, Upper						
6	KC10ACHDZV06	Furniture Guard						
7	KC34PCHDZV06	Nozzle Hose Manual Musica Manual 5						
8	8192229	Thermal Protector Unit						
9	8192239	Lead Wire, Brown						
10	KC02LBBRZ000	Filter						
11	8192240	Lead Wire, Blue						
12	8192221	Motor Support Rubber (Right)						
13	8192267	Motor Assembly						
14	8174945	Internal Gear						
15	8174944	Screw						
16	KC83CCHDZ000	Gear Unit						
17	8174928	Washer						
18	8192278	Nut						
19	KC56RCRCZ000	Agitator Tube, Tufted						
20	8192279	End Cap Unit 14 14 14						
21	8174908	Motor Support Rubber (Left) 15 15 16 17 18 19 19 19 19 19 19 19 19 19						
22	KC57HCHDZV06	Sliding Knob Height Adjust						
23	KC47ACRCZV07	Pedal Plate Pedal Plate						
24	8174907	Carran						
25	4368563	Screw Felt Seal, Lower						
26	KC11ACHEZ000	Lower Plate						
27	KC27ACHDZV07	Height Adjust Actuator						
28	KC34HCHDZV07	Nozzle Roller Unit						
29	8192525	Spring, Round						
30	NOT SERVICED 4370183	Rubber Cushion 19						
31	KC01CAVGZV06	Wheel 20 / 23						
32		Washer						
33 34	NOT SERVICED NOT SERVICED	Roller Shaft						
	KC53MCHDZ000	27_						
35 36	KC94UCHDZ000	Spacer Gear Assembly						
37	KC40RCRCZ000	Spring						
31	10401101102000	Spring 25 25						
* Av	ailable At Any Sears	s Retail Store						
Αν	anable At Arry Coun	25						
a some state of the second state of the second seco								
	25							
	29							
		14868-784-642 [
		30-000000000000000000000000000000000000						
		24 /22 / 33 34 22						
		31 32 33 34 33 33						

DUST COMPARTMENT AND MOTOR PARTS



DUST COMPARTMENT AND MOTOR PARTS

Illus.	Part No.	DESCRIPTION	Illus No.	Part No.	DESCRIPTION
1	KC84PCRCZV06	Hose Unit	35	KC74ECSRZ000	Seal
2	4368563	Screw	36	KC55LCRCZ000	Air Guide - Right
3	KC66PCSRZV07	Tool Caddy	37	KC54LCRCZ000	Air Guide - Left
4	KC11KCRCZV07	Bag Supporter	38	KC48HCRCZCU7	Dust Cover Door
5	KC68ECJNZ000	Plug (Female)	39	KC92FCJNZ000	Fan Motor
6	KC89VCSRZ000	P.C.B. Microcontroller	40	KC10GCHDZ000	Motor Enclosure
7	4370575	Suction Inlet Packing	41	KC99WCHDZ000	Lead Assembly
8	4369538	Cord Stopper	42	KC43GCHEZ000	Lead Wire, White
9	KC74KCRCZ000	Dust Compartment Packing	43	KC38GCMSZ000	Lead Wire, Red
10	KC70PCRCZV07	Extension Wand Holder	44	KC48GCHEZ000	Lead Wire, Brown
2 11	4368653	Main Switch - On/Off	45	KC41GCHDZ000	Lead Wire, Blue
12	KC43GCHDZ000	Lead Wire, White	46	KC48GCMTZ000	Lead Wire, White/Black
13	KC48GCMSZ000	Lead Wire, White/Red	47	8191894	Lead Wire, Black
14	KC40KCRCZV07	Dust Container	48	KC38GCHEZ000	Lead Wire, Yellow
15	KC47VCSRZ000	Indicator Display	49	KC60KCRCZC07	Dust Cover
16	KC08MCSRZ000	Indicator Window	50	8175134	Power Cord
8 17	KC41KCRCZV07	Filter Cover	51	KC02HCRCZV07	Filter Door
18	KC87GCSRZ000	Dirt Sensor	52	4370408	Protector Cover
19	KC53PCHEZV06	Hose Hook	53	KC66KCRCZ000	Dust Cover Packing
20	KC53PCHDZV07	Hose Hook	54	KC93HCHEZ000	Bulb Socket
21	8175062	Exhaust Filter	55	8192266	Bulb
21	0170002	*Sears No. 20-86889	1		*Sears No. 20-5248
		Kenmore No. EF-1	56	KC21HCHDZ000	Window
22	KC74KCSVZ000	Dust Comaprtment Packing	57	4368522	Wire Nut (Large)
23	8174943	Locking Cam	58	8174824	Wire Nut (Small)
24	8192713	Screw	59	4370779	Handle Screw
25	KC21TCRCZ000	Label	60	KC13ECRCZ000	Nozzle Spring Nut
26	4369561	Roller Shaft	61	KC16KCMPZ000	Dust Bag
27	4369562	Washer			*Sears No. 50690
28	4370812	Wheel	P Jolley		Kenmore No. O
29	4369564	Stopper Wheel	62	4369572	Secondary Filter
30	4370429	Protector	63	KC02FCJNZ000	Motor Support, Rubber
31	KC70KBXZZY00	Protector Spring	64	4370574	Vac Tube Switch
32	KC85VCJNZ000	P.C.B. B Unit	65	KC62PAXKZ000	Indicator Tube
33	KC45LCRCZ000	Air Outlet Packing	13		
34	KC28LCSRZV07	Air Outlet Guide	*Ava	ailable at any Sears F	Retail Store


HANDLE PARTS

rble for Purchase at For Model: 116.35922500, 116.35923500

No. 1 2 3 4 5		DESCRIPTION Label Handle A P.C.B. Assembly Plug (Male) Handle B	-2	 5	
6 7	8192573 4368563	Cord Hook Screw		77	6
			4	7	KC012C KC402C KC302C KC302C
			o B	D	1

ATTACHMENT PARTS

Illus.	Part	
No.	No.	DESCRIPTION
1	4368684	Crevice Tool
2	8192260	Combination Brush
3	8192261	Brush, Holder Tufted
4	8192294	Fabric Brush
5	KC80SBPNZV06	Handi-Mate Jr.
6	4370414	Extension Wand
7	4368996	Suction Regulator
8		LITERATURE PARTS
	KC01ZCRCZ0U0	Owner's Manual
	KC40ZCRCZ0U0	Repair Parts List
	KC30ZCSRZ000	Label, Wiring Diagram
9	4369007	Extension Wand
10	KC96RCSRZV06	Floor Brush



List of Parts and Accessories Available for Purchase at **Sears Stores and Parts and Repair Centers**

/	Item No.	Style No.		Available at Any Sears Retail Store	Available through Sears Parts and Repair Centers
Filte	rs 86880	EF-2	HEPA Exhaust Filter for Kenmore Vacuums		Tropan Conters
	86883	CF-1	Bag Chamber Filter for Kenmore Canister Vacuums		
	86884	CF-2	Bag Chamber Filter for Kenmore Upright Vacuums		
	86885	CF-4	Bag Chamber Filter for Kenmore Canister Vacuums		
	86886	eon cli oor	Bag Chamber Filter for Kenmore Upright Vacuums		
	86887	ng s yste	Exhaust Filter for Kenmore Upright Vacuums		
	86888	CF-3	Bag Chamber Filter for Kenmore Upright Vacuums		
	86889	EF-1	HEPA Exhaust Filter for Kenmore Vacuums	\checkmark	
	86890	92-096	Exhaust Filter for Kenmore Vacuums	in uppli losi	
	82720	DCF-1	Tower Filter for Kenmore Bagless Upright Vacuums	/O	
	82728	enalidad	Primary Filter for Kenmore Bagless Upright Vacuums		
	82912	DCF-2	Tower Filter w/Cap for Kenmore Bagless Upright Vacuu	ıms 🗌	
Bag	gs 5055	С	Canister Vacuum Dust Bags	H L	
	50557	Q	Canister Vacuum Dust Bags		
	50558	С	Canister Vacuum Dust Bags		
	50690	0	Upright Vacuum Dust Bags	\checkmark	
	50688	U	Upright Vacuum Dust Bags	oli in is f	
Attachmen	ts 2405		Electric hose for canister vacuums	The same	
	2808	equ ip me	Electric hose canister vacuums		
	52581	Jeanear	Super Reach-Out Extension Hose	\checkmark	\checkmark
	52631	ter	Crevice Tool	\checkmark	\checkmark
	52641	(Chama)	Dusting Brush	V	\checkmark
	52651	(s	Fabric Brush	\checkmark	
	52682	186-PAR	Bare Floor Brush Accessory	\checkmark	
	52050	A hooles	Handi-Mate Jr.® Accessory for Kenmore Vacuums		
	52040	NAME OF STREET	Power-Mate Jr.® Accessory for Canister Vacuums	BURGINSE	67°,
Bulb	s 5240	SOS UL GO	Bulb (A & U) & CO 3-15	9-108-1	
	5248	tie Barve	Bulb	\checkmark	
Belt	s 5285	CB-1	Cogged Belt	BLAND STORY	
	5201	CB-2	Whisperbelt for 14" Power-Mate®		
	5215	UB-7	Rear Belt for Dual Agitator Upright	1)	
	5279	UCB-1	Flat belt for 12" Power-Mate®		
	5275	UB-1	Belt for Kenmore Progressive Upright Vacuum		
Other	s 50042		Scented Tablets (12 tablets per package)		
V Indicate	s availability	at Sears an	d compatibility with your vacuum cleaner		